## TRUETONE MODEL CYJ4832-A -87

Adjust RV2 for maximum modulation. Adjust L7, L11, and L12 for maximum power.

VECTOR MODEL X

Cut D260 and D261 for maximum modulation. Adjust L53, L55, L57, for maximum power.

DELCO MODEL 70BFMC3

Adjust RV2 for maximum modulation on CB chassis next to transistor heat sink and transformer at right rear of PC board.

PACE MODEL 8008

Cut CR18 and CR19 for maximum modulation. They are located near audio output. Transformer and 1.C. audio amp. at right center of PC board.

BOMAN MODEL CB-750

Adjust FVR-3 for maximum modulation, located near center of PC board, 2/3 way from front panel.

KRIS XL25

Adjust VR6 for maximum modulation, located on front side of T7 transformer at center rear of PC board.

LAFAYETTE MODEL HB640

Adjust RV2 for maximum modulation located near right rear of board by transformer.

RCA MODEL 14T300

Adjust RV102 for maximum modulation.

SEARS ROADTALK 40

Cut Diode D501 for modulation.