TRUETONE CYJ4837A-87

Adjust T6, L7, L11, and L13 for maximum power. Adjust RV2 for SSB power. Adjust VR4 for maximum AM power. Adjust RV12 for 100% modulation. Adjust RV11 for SSB mike gain.

UTAC TRX400

Adjust L14 and L15 for maximum power. Adjust VR7 for 100% modulation. Adjust VR8 for RF panel meter adjustment. Connect pin 10 of IC501 to 4.30V source and Connect pin 11 of IC501 to 4.30V source for more frequencies.

HYGAIN VIII

Adjust RV608 for AM power adjustment.

RV7: AM mike gain adjustment RV8: SSB mike gain adjustment. RV5: SSB automatic level control adjustment

RV3: RF panel meter adjustment.

SEARS ROADTALKER 40 CM-6000LA

Clip D501 for 100% modulation.

SEARS CM6000LC

Clip D7 for 100% modulation.