



Consumer Response Group

6500 W. Cortland Street * Chicago, IL 60707 * Phone: 773-889-8870 * FAX: 773-622-2269

August 26, 2003

Page 1 of 1

TECHNICAL SERVICE BULLETIN 10025

- MODEL(S):** All CB models
- DESCRIPTION:** Intermittent transmit, intermittent receive, intermittent modulation, squealing on transmit or receive, or other erratic behavior.
- ACTION:** Service hint: Tighten PCB mounting screws.
- Before attempting other troubleshooting analysis, tighten the PCB mounting screws. If this solves the problem, then it is recommended to install internal tooth lockwashers on the screws to maintain a reliable ground connection.
- ADJUSTMENTS:** None.
- NOTES:** Suitable lockwashers can be obtained from local hardware stores. External tooth lockwashers are acceptable but **do not** use split ring lockwashers.