



VI - 12BA6 (12V)
6BA6 (6V)
RF. AMPL.

V2 - 6J6
MIXER

V3 - 6BE6
CONVERT.

V4 - 12BA6 (12V)
6BA6 (6V)
I.F. AMPL.

V8 - 6AU8
RCVR. OSC. - XMTR. OSC.

V9 - 12AQ5 (12V)
6AQ5 (6V)
RF POWER AMPL.

V6 - 12AT7
SP. AMPL.

V7 - 12BH7
MODULATOR &
AUDIO OUTPUT

SO 5
EXT.
SPEAKER

3.2 OHM
SPEAKER