



NOTE: Remove C45 and C50
and replace C45 with a
100K resistor on the back of PCB

NOTE: C18 is removed on the back of PCB

NOTE: Change C57 (C5)
and remove C58 (C4)
for better AM Reception