

TEABERRY STALKER XX, MB8734

Frequency Modification-

1. Remove the MB8734 chip
2. Replace with a MB8719 chip.
3. Unground pin 10.
4. Change X4 to 11.3258 Xtal.
5. Use conversion found on pages 25 to 27.

Clarifier-

1. Remove D36.
2. Cut ORANGE wire off of the clarifier control and tape.
Run a new wire to pin 1, IC5
3. Clip R187.
4. Replace D37 with a Super Clarifier Diode. CT3, USB;
L20, AM; L19, LSB.

Tune-up -

L13.....VCO
Tune L26, L27, L28, L29, L36 on USB.
VR12.....Modulation Meter.
VR8.....RF driver bias (30ma idle current)
VR9.....RF final bias (50ma idle current)
VR5.....Carrier Balance.
VR7.....RF ALC.
VR6.....AM power.
VR10.....RF power meter.
VR11.....AMC(or remove TR32).